


Development of an Ionic Liquid Modified Carbon Adsorbent for Treating Emerging Contaminants in Recycled Water on the International Space Station




Savanna Vacek
Mentor: Dr. Erica Marti

Department of Civil and Environmental Engineering, University of Nevada - Las Vegas




Introduction

- The International Space Station (ISS) operates as a closed system
- Water is recycled from humidity and urine and held in a wastewater tank; part of the Water Processing Assembly (WPA)
- Potable treated water is used indirectly in the Sabatier Reactor
- The Sabatier Reactor is a key component in the Environmental Control and Life Support System (ECLSS)
- Three main functions of ECLSS: water recovery, air revitalization, and oxygen generation
- Sabatier Reactor recently failed due to contamination of DMSO₂, dimethyl sulfone, and DMSD, dimethylsilanediol
- DMSO₂ and DMSD are emerging contaminants that are not removed by the media used in the WPA due to their low affinity
- DMSO₂ and DMSD are introduced into the water system through personal hygiene products such as lotion, conditioner, and wipes, which all contain volatile methyl siloxanes (VMS)
- VMS are decomposed into DMSO₂ or DMSD and are found in urine



International Space Station Water Processing Assembly - Graphic Credit: Dr. Khan's Lab

- Ambersorb 4652, a styrenic polymer adsorbent that is not biobased or sustainable, is the current media used in the multifiltration beds in WPA on the ISS
- Costly and unsustainable, Ambersorb 4652 is challenged to remove DMSD and DMSO₂ from recycled water
- Granular activated carbon (GAC) works similarly to a styrenic polymer adsorbent and can be made from biobased materials
- Ionic liquids are liquid molten salts at temperatures < 100 °C that are typically composed of large and unsymmetrical organic cations and organic or inorganic ions
- Composed of a hydrogen bond acceptor (HBA) and a hydrogen bond donor (HBD)
- Remarkable solvation ability for a broad range of natural and synthetic materials and compounds



Research Objectives

- Objectives:**
- Synthesize at least 3 biobased ionic liquids
 - Analyze and quantify how much DMSO₂ is removed by the ionic liquids through liquid-liquid extractions
 - Coat GAC with the most effective biobased ionic liquids
 - Analyze and quantify how much DMSO₂ is removed with uncoated GAC and ionic liquid coated GAC through batch adsorption testing


Preliminary Work

- The following ionic liquids were synthesized: a liquid result is successful, but any recrystallization is an unsuccessful result

HBA	HBD	Molar Ratio	Result
Thymol	Decanoic Acid	1:1	Liquid, oil-like viscosity
Thymol	Decanoic Acid	2:1	Liquid, oil-like viscosity
Thymol	Decanoic Acid	1:2	Liquid, water-like viscosity
Thymol	Undecylenic Acid	1:1	Liquid, water-like viscosity
Thymol	Undecylenic Acid	2:1	Liquid with some recrystallization
Thymol	Undecylenic Acid	1:2	Liquid, water-like viscosity
Thymol	Dodecanoic Acid	1:1	Completely recrystallized solid
Thymol	Dodecanoic Acid	2:1	Liquid with some recrystallization
Thymol	Dodecanoic Acid	1:2	Completely recrystallized solid


Synthesized Ionic Liquid Results

- Liquid-liquid extractions (LEE) were conducted to determine the efficacy of ionic liquids to remove DMSO₂ from water
- Ionic liquids were mixed with DMSO₂ contaminated water, centrifuged, and separated to remove ionic liquid from water phase




Ionic Liquid DMSO₂ Removal Percentage

- GAC was coated by combining 1 g GAC, 0.5 g ionic liquid, 15 mL methanol, and shaken in an orbital shaker for 24 hours
- GAC was separated using vacuum filtration and oven dried at 103 °C for 1 hour
- Scanning electron microscopy (SEM) was conducted to ensure coating of ionic liquids onto GAC



Naked/Uncoated GAC

Preliminary Work Cont.




Thymol & Decanoic Acid 1:1 Coated GAC

Thymol & Undecylenic Acid 1:2 Coated GAC


Methodology

Equilibrium Batch Adsorption Testing with Uncoated GAC:

- 100 mg of coconut granular activated carbon ranging in sizes from 400-595 microns is added to a 45 mL vial containing 800 ppb DMSO₂
- Solution is shaken until reaching equilibrium
- Equilibrium time is determined by taking samples over time - 24, 48, 72, and 96 hours
- Samples are filtered to separate GAC from water
- Samples are analyzed by gas chromatography mass spectrometry (GCMS) to measure the concentration of DMSO₂



Results



Uncoated GAC Equilibrium Batch Adsorption Test Results

Discussion/Conclusion

Batch Adsorption Testing:

- 0 hours started with 756 ppb of DMSO₂
- Over 24-96 hours, concentration stayed relatively the same around 515 ppb DMSO₂
- 24 hours can be determined as the equilibrium time with only a 32% removal
- Demonstrates a need for ionic liquid coated GAC since uncoated GAC is not sufficient in removing DMSO₂ from water

Future Work

- Naked/Uncoated GAC will finish going through batch adsorption tests - isotherm and kinetics testing
- The two ionic liquid coated GACs will go through batch adsorption tests - equilibrium, isotherm, and kinetics testing
- The results of the adsorption experiments will be analyzed to determine the removal of DMSO₂
- If removal was successful, the ionic liquid coated biochar would be a good recommendation to fix the Sabatier Reactor
- Naked and coated GACs will also go through same rounds of batch adsorption for DMSD
- Method will be developed on the GC-MS to quantify amounts of DMSD leftover in water after batch adsorption testing

Acknowledgements

This material is based upon work supported by the National Aeronautics and Space Administration under Grant No. 80NSSC20M0043. I would also like to thank Dr. Erica Marti, Dr. Eakalak Khan, Gabson Baguma, and Madeline Carroll for their help and contributions.



References

Please view the PDF for references via QR code

